

0812 Safety Guidance



## **Using the Pressure Washer**

- Wear protective equipment including goggles and waterproof overalls
- Hold the lance in both hands when squeezing the trigger because the water pressure will make it 2. "kick back"
- Do not aim the water jet at yourself, any other persons, or any animals. It will cause an injury.
- Do not spray the water jet over any electrical equipment. This could cause a short circuit and fire. This could cause a fatal electric shock.
- If the cable is cut or damaged in any way, dry your hands switch off and unplug at the mains before inspecting it. If the cable attached to the pressure washer is damaged, stop using the equipment. Contact the hire company. If an extension cable has been damaged do not use it
- If you suspect there is a fault in the electricity supply to the socket, do not attempt to repair it. Contact a competent electrician
- Take care not to accidentally pull the plug from the socket.
- 8. Switch off and remove the plug from the socket before leaving the machine unattended.
- 9. Do not connect or disconnect a pressure hose or lance while the washer is pressurised. Turn off the water pump motor, and squeeze the lance trigger to release the pressure.
- Switch off the washer at the mains and squeeze the lance trigger to release the pressure when not in use
- 11. If working in cold conditions, make sure that the water in the machine will not start to freeze when not in use.
- 12. After work turn the detergent off or remove the detergent feed. Run the washer on just water to flush the detergent out. Then turn off the water pump motor, and squeeze the lance trigger to release the pressure. Dry hands, switch off at the mains and unplug the washer.
- 13. Drain the machine if there is any danger of overnight frost.
- 14. Make sure that all the water filters are cleaned and properly protected before storing the machine
- If the equipment does not work properly do not attempt to repair it. Contact the hire company. Keep this leaflet safe as it may be required for reference at a future date







2450 Regents Court

The Crescent









44 (0) 121 333 4109



©Copyright Hire Association Europe April 2011 Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

#### are dry and sare Make sure that any extension cable connections

Unroll it fully or it will overheat and could catch doorways or windows where it might be trapped, and places where vehicles might run over it. Lay it out carefully avoiding liquids, sharp edges,



teet). Plug it directly into the rcd. splash proof socket, not longer than 50 metres (160 use a suitably rated heavy-duty extension cable with a instructions, you should only sbecial guλ the hire company have not

sbecisi instructions given by the nire company. It If you need to use an extension cable, follow any

according to the instructions supplied with it. working each time you use it. Reset the rcd Use the "TEST" button to check that the rcd is

gets damaged. against electric shock if the cable or equipment

will help to protect equipment into the rcd. This the 230volt socket. Plug the ("rcd") plugged directly in to Use a residual current device

#### (SQUARE PIN OR BLUE PLUG) 230 VOLT EQUIPMENT

are dry and sare. 4. Make sure that any extension cable connections

overneat and could catch life. vehicles might run over it. Unroll it fully or it will liquids, sharp edges, doorways or windows where it might be trapped, and places where Lay the extension cable out carefully avoiding

between the transformer and the equipment. proof socket, not longer than 50 metres (160 feet). You must only use an extension cable instructions, you should only use a suitably rated heavy duty 110v extension cable with a splash



have not given any special instructions given by the hire company. If you need to use an extension cable, follow any special not use any 230v extension cables.

If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do

### 110 VOLT EQUIPMENT (YELLOW PLUG)

Read the instructions below for your equipment. bing fitted, or a blue industrial plug.

230v equipment will have either a normal square pin industrial plug fitted.

be 110v or 230v. 110v equipment will have a yellow The equipment will only operate on one voltage: it will

#### ELECTRICAL SUPPLY

fitted to the pressure washer, with a splash proof the same neavy-duty specification as the cable IT you have to use an extension cable, it must e working at a distance from the electricity supply.

Using extension hoses is a much safer way of

- Do not use an extension cable unless it is petore you plug it in to the supply.
- Make sure the pressure washer is switched off
- nuiess your nands are dry. Do not tonch any switches, plugs, or sockets

#### ELECTRICAL SAFETY

песоппленией аегегдени. instructions supplied with them. Use only the















# **Pressure Washer**

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

#### It is important to read all of this leaflet **BEFORE** you use the Pressure Washer

- 1. Plan the use of the pressure washer so it can always be used safely.
- Electricity is dangerous and must always be used with great care.
- Water and electricity make a dangerous combination. Keep water away from electrical parts.
- This pressure washer is designed for high pressure water washing.
- The action of this pressure washer can cause injury or damage if the equipment is not used in a careful and controlled way.
- If you have not used a pressure washer before, take time to familiarise yourself with how the equipment works before starting to use it.
- Plan and think ahead to make sure you will always be working safely.
- The following personal protective equipment should always be worn Impact resistant visor or goggles; Waterproof overalls; Waterproof boots; Gloves; Red if using a 230 volt (mains) supply.
- This equipment must not be used by minors, or by anyone under the influence of drugs or alcohol.
- This pressure washer is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.















Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting materia eading. HAE/EHA cannot accept responsibility for any loss or liability pero of any such document/material. Only Acts of Parliament and Statutory Ins rom the use of any such document/material. Only Acts of Parliament and Statu-have the force of law and only the courts can authoritatively interpret the law.

> 44 (0) 121 333 4109 44 (0) 121 380 4600

The Crescent Birmingham Business Park noo sinegen uce

**BAY 788 Iludilos** 

your supply. Do not try to force connections or

Check that the plug on your equipment matches

anything is found damaged, do not use the

pressure water noses and an equipment. It

Check the pressure washer, cables, plugs, high

need to wear appropriate personal protective

Anybody who is working near to you will also

You should wear overalls, boots, and gloves that

Impact resistant visor or goggles must be worn

washer. Particular jobs or environments may

be worn whenever you use this pressure

ednibment (ppe) are the minimum that should

The following items of personal protective

or water being sprayed onto the electricity

Zet up the work area so that there is no danger

aure you have good drainage for the waste

when working with this machine.

require a higher level of protection.

pressure washer contact the hire company.



improvise mem.

PRESSURE WASHER

are waterproof.

**SHOTARIANO** 

горыу зоскег

3. If using chemicals or detergents, follow the doubt about how clean your water supply is.

You must use a suitable filter if you are in any

water is ciean.

If your supply is from a water tank make sure the **WATER SUPPLY** 

Before you switch on the washer, you must know how to control it and switch it off safely. Make sure you understand all of the controls qirty when you are setting-up the machine.

Make sure that none of the hose connections get

connections are firm and tight. Make sure that all the pressure hose 'elaissod

ision hoses instead of extension cables if away from the electricity supply, without having to use long extension cables. Always use Extension hoses may have been supplied by the hire company. These allow you to work further from where vehicles may run over it.

Ensure it is laid out safely with no kinks, away Use only the hose supplied with the machine. one industrial plug.

have either a normal square pin plug fitted, or a designed to run directly from 230v mains will it may be heavier than you think. Equipment care not to injure yourself when moving it about а роггаріе тгалѕготтег паѕ вееп ѕирріїец, таке edulpment from a normal mains 230v supply. It portable transformer if you need to power the supply. The hire company will have provided a ping titted is designed to run off a special 110v Ednibuseut Mitu s cylindrical yellow industrial



that no-one is near to you or could distract you. Make sure that the area is clear and safe and where the electrical parts might get wet.

Do not use this pressure washer in the rain or

betrol, or gas cylinders. a danger of explosion. It will ignite fumes from Do not use this pressure washer where there is

**WUKK AKEA** 

# Betore Starting Work.